

INSTALLATION GUIDE PML-Working Around Corners

Traditional Wallpaper - Applying wallpaper around wall corners and edges

These notes provide guidance on how to apply wallpaper around or into wall corners in order to avoid unsightly gaps.

Before You Start

Please refer to the **Installation Guide** and **Layout Guide** supplied with your Printamural product.

Working Around Wall Corners

Installing our wallpaper around or into wall corners is straight forward.

We recommend that you do not trim away the wallpaper 'drop' excess at the corner or edge but instead fold and paste it down onto the adjacent wall, and then paste the over-lying wallpaper 'drop' on top of it.

When you are applying the over-lying 'drop', and to avoid cutting through the under-lying wallpaper, we recommend that you do not trim the corner excess off with a knife once you have applied it. Instead, we recommend that you use a pencil to mark the edge or corner line on the front surface of the 'drop', peel it back and then use scissors to trim off the excess before pasting it down.

You may use border paste to apply the over-lying wallpaper onto the wallpaper below. This is particularly useful for a firmer fix along exposed edges.

If you have any questions or if you require any further assistance with measuring up and choosing the right mural for your wall space, then please do contact us. We are always happy to help.

These notes are intended for your general guidance. Printamural cannot accept any liability with regard to the use of this information, or for any misinterpretation of the information provided.

For more information or guidance, please call us on 01827 383194 or email info@carehomemurals.co.uk or visit www.carehomemurals.co.uk.

Copyright Care Home Murals 2021 v5.1