

INSTALLATION GUIDE PML-RML

Rollamural

Before You Start

Please take time to review these instructions before you start your installation.

We suggest that the installation is carried out by two people.

Tools You Will Need

- Tape Measure
- Spirit Level
- Small Drill
- 4no Screws and/or Wall Fixings
- Screwdriver
- Stepladder
- Pencil

Rollamural Contents

Carefully unpack your Rollamural.

- Rollamural printed fabric attached to roller bar with chain and mechanism attached
- 2no Brackets with End caps
- 1no Safety Clip
- 1no Safety Label

Choose a Fixing Method

You can fix toy Rollamural directly to the wall or fix it to a batten.

If you choose to fix directly to the wall, you will need 4no screws and/or wall fixings of a suitable size and nature appropriate for fixing to your type of wall.

If you choose to fix to a wood batten that you have already fixed to your wall, you will need 4no screws at least 18mm long.

Positioning Your Rollamural

Although Rollamural is designed to display at a suggested height above the floor, you may of course position your Rollamural at any height you choose to suit your application.

A Rollamural 120(W) x 240cm(H) is designed to be positioned around 240cm above the floor.

A Rollamural 100(W) x 200cm(H) is designed to be positioned around 200cm above the floor.

When you have chosen the position and height for your Rollamural, make a pencil mark on the wall or batten at the height and at the centre line of the Rollamural.

Fixing the Brackets

For a Rollamural 120cm wide, we suggest the fixing holes for the brackets should be approx. 1206mm apart. However, you should determine the distance that works best for your application.

For the side of the Rollamural with the chain, make a mark 606mm from the centre line. For the other end, make a mark 600mm from the centre line.

For a Rollamural 100cm wide, we suggest the fixing holes for the brackets should be approx. 1006mm apart. However, you should determine the distance that works best for your application.

For the side of the Rollamural with the chain, make a mark 506mm from the centre line. For the other end, make a mark 500mm from the centre line.

The bracket with the rectangular slots should be used to attach the end of the Roller Bar with the chain mechanism.

Position the first bracket with its fixing holes in line with the mark, use the pencil to mark the position of the two fixing holes and drill 2 pilot holes.

Fix the bracket in place with suitable screws.

Position the second bracket with its fixing holes in line with the mark, and use a spirit level to check that it is level with the first bracket. Then mark the position of the two fixing holes and drill 2 pilot holes.

Fix the bracket in place with suitable screws.

Attaching the Roller Bar

Fit the end of the Roller Bar with the chain mechanism into the appropriate bracket, ensuring that the chain cover is at the top and the chain falls correctly.

At the other end of the Roller Bar, press the sprung axel and insert it into the hole in the bracket. Ensure that the sprung axel releases itself and holds the Roller Bar in place.

Lastly, fit the Safety Clip to the chain and wall. Attach the clip to the chain and locate it at the lowest point of the chain. Then screw fix the clip to the wall so that the chain is maintained taut and close to the wall.

Alternatively, you may prefer to attach the clip to the wall at a point level with the top of the Rollamural in order to ensure the chain is maintained well out of reach.

Optionally, fit the Safety Label to the chain.

Rollamural Operation

Use the chain to lower and raise your Rollamural.

If you have any questions or if you require any further assistance, then please do contact us. We are always happy to help.

These notes are intended for your general guidance. Printamural cannot accept any liability with regard to the use of this information, or for any misinterpretation of the information provided.

For more information or guidance, please call us on 01827 383194 or email info@carehomemurals.co.uk or visit www.carehomemurals.co.uk.

Copyright Care Home Murals 2021 v5.1